GIB[®] Downloading GIB EzyBrace[®] Software from the GIB[®] website.

There have been a number of issues downloading and installing GIB EzyBrace[®] Software from the GIB[®] website. This is a web hosting issue and often occurs when the user has the Windows 10 Operating System.

If there is a problem downloading and installing it is suggested that the programme be downloaded from Dropbox. The below instructions should be followed for installation.

Windows Installation

The Windows download is located in the Dropbox <u>https://www.dropbox.com/s/allkifrycvugcjn/GIB%20EzyBrace%202011%2012-18a.zip?dl=0</u>

01. Click on the link, the following window should be displayed:

	GIB Ezybrace® 12-18u.zip	Download •
Vame	Size	S) Com
	21.96 KB	
GIB EzyBrace©.msi	1.82 MB	
👄 Setup.ini	5.05 KB	
program files		
ø setup.exe	1.23 MB	

02. Click on the 'Download' button and choose 'Direct Download'. Once downloaded open the archive (zip) file to open the below window.

03. Click on the 'Extract All' button.

N 🖓		Compressed Folder Tools	GIB Ezybrace® 12-18u					- 🗆 ×		
File	Home Share View	Extract						0		
🛗 My D	ocuments	Pictures	003 3D Renders							
2019	EVENTS	01 Calendars	Marketing Services Coordinator Role 👻							
Partn	ership Agreements	Info and Templates	2019 Extract all							
		Extract To								
← → ✓ ↑ 📳 > This PC > Downloads > GIB Ezybrace [®] 12-18u										
^	Name	Туре		Compressed size	Password	Size	Ratio	Date modified		
<u> </u>	program files	File folder						19/07/2019 11:17		
	🔬 0x0409	Configuratio	n settings	5 KB	No	22	KB 81%	1/10/2014 9:41 A		
•	🔂 GIB EzyBrace®	Windows Ins	taller Package	527 KB	No	1,866	KB 72%	19/07/2019 11:17		
	📧 setup	Application		545 KB	No	1,263	KB 57%	19/07/2019 11:17		
	ලු Setup	Configuratio	n settings	2 KB	No	6	KB 75%	19/07/2019 11:11		
5 items	<							8== 6		

04. Click the 'Extract' button and the archive will be extracted into a new folder called 'GIB EzyBrace® 12-18u'.

~	Extract Compressed (Zipped) Folders			2
	Select a Destination and Extract Files			
	Files will be extracted to this folder:			
	C:\Users\sarah.joblin\Downloads\GIB Ezybrace® 12-18u		Browse	
	Show extracted files when complete			
		Extr	act Ca	incel

05. Open the folder and double click on the setup.exe file. The programme should then run through the installation process. Once installed the 'GIB EzyBrace[®] 12-18u' folder can be deleted.

- I 🖓	<mark></mark> - G	ilB Ezybrace® 12-18u										_
File	Home	Share View										
Pin to Quic access	to Quick Copy Paste Copy Paste Paste shortcut		Move to *	Copy to *		New folder	New item ▼ 1 Easy access ▼ 1 Folder		Properties		Select all Select none	
	CI	ipboard	Organize				New			Open	Select	
← → ✓ ↑ 📴 > This PC > Downloads > GIB Ezybrace® 12-18u ✓ ♂ Search GIB Ezybrace												
^	Name			Date modified		Туре	Type Siz					
*	pro	gram files	26/11/2019 4:41 PM		File fol	File folder						
🔂 0x0409		409		1/10/	2014 9:41 AM	Config	uration sett		22 KB			
CID EL, Browe			19/07/2019 11:17			Windo	Windows Installer		1,866 KB			
🔄 🐸 setup.exe				19/07	//2019 11:17	Applic	Application		1,263 KB			
E	Setup.ini		19/07/2019 11:17		Config	Configuration sett		6 KB				

Mac Installation

The Mac version is available for download here:

 $\underline{https://www.dropbox.com/s/esq6v1sp8eb5jgh/GlB\%20EzyBrace\%C2\%AE.pkg?dl=0}$

01. Click on the link and the below window will be displayed.



02. Click the 'Download' button and save the download. Once downloaded, double click on the 'GIB EzyBrace[®].pkg file name to run the installation process.